

SIGNO BK - PVC

INSTALLATION OF MOULDED ACCESSORIES FOR SIGNO BK – 70MM DEPTH TRUNKING

Installation Internal Corner

1 Trunking is installed butted next to each other (max 5cm gap between trunking from the front). Feed the cables through, guiding them freely around the corner. Place the internal corner over both ends of the trunking and clip on.



2 Using the thumb and index finger snap shut the corners right, left, top and bottom. Push main lid under the moulding into the clips of the main base (overlap 10mm).



3 Install lids accordingly, cut to length.



Installation External Corner

1 Trunking is installed butted together at the base side (max gap 5cm). Place external corners over the trunking and clip on by pressing down with both hands.



2 Using the thumb and index finger snap shut the corners right, left, top and bottom.



Installation Flat Angle

1 Apply the enclosed tape on the corners of the flat angles for secure fitting. Both external and internal flat angles are placed over the trunking, press on with both hands.



2 All four corners to be snapped shut with thumb and index finger. Insert the lid and push it under the flat angle into the clips of the base (over lap approx 10mm).



3 Lids cut to length, to be installed accordingly.

Installation Endcap

1 Place endcap onto the trunking, clip in at top and bottom. Additionally the endcap can be screwed into the trunking for additional security. Insert lid and push under the endcap (approx 10mm).



Click-to-fit Fast Coupling

1 -The click to fit coupler is located in the side wall of the trunking, ex-works
- Due to the spring clip the coupler can not be pushed back
- Simply push the next piece of trunking onto coupling clip

