

---

# TECHNICAL BULLETIN TB270

## USE OF TRACER WIRE ON MUNICIPEX<sup>®</sup> PIPE

Product: **MUNICIPEX Pipe**  
Date: **16 October 2017**

REHAU approves of the use of tracer wire (for locating buried pipes) with MUNICIPEX pipes, provided that the manufacturer's installation instructions approve of the product's use with plastic pipes and all the manufacturer's instructions are followed.

When attaching tracer wire to MUNICIPEX pipe, REHAU recommends using Linerless Rubber Tape, Black (Art. 241002), also sold as Scotch<sup>™</sup> 2242; REHAU Protective Tape, Red (Art. 246869-001); or nylon pipe ties.

MUNICIPEX pipes must be installed in accordance with local codes and published REHAU installation instructions. Tracer wire should be in accordance with the local specification. Please check with local authority having jurisdiction.

For updates to this publication, visit [na.rehau.com/resourcecenter](http://na.rehau.com/resourcecenter)

The information contained herein is believed to be reliable, but no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for particular applications or the results to be obtained therefrom. Before using, the user will determine suitability of the information for user's intended use and shall assume all risk and liability in connection therewith.

© 2017 REHAU