# RAUVISIO terra™ Soft, Textured HPL Surface Laminate

Section 06400

Architectural millwork specification information

# 01 General

### 1.1 Related sections

A. Section 06410 - Custom cabinets

B. Section 12320 - Manufactured wood casework

C. Section 12350 - Specialty casework

#### 1.2 Submittals

A. Submit under provisions of Section 01300

B. Manufacturer's data sheets on product being used

1. RAUVISIO terra technical information

# 1.3 Quality assurance and testing

A. Installer qualifications: Cabinet/millwork professional

B. Testing information can be found in the RAUVISIO terra technical information

#### 1.4 Storage and handling

A. Store products in manufacturer's unopened packaging until ready for installation.

B. Store in dry, protected, well-ventilated area and protect from damage.

C. Store away from dust and debris.

## 1.5 Safety

A. To ensure safety and proper use of the product, follow manufacturer's safety guidelines found in the RAUVISIO terra technical information.

## 1.6 Project conditions

A. Maintain environmental conditional (temperature, humidity, and ventilation) within limits recommended by manufacturer for optimal results. Do not install products under environmental conditions outside manufacturer's absolute limits.

## 1.7 Warranty

A. Provide manufacturer's limited warranty

# 02 Products

## 2.1 Manufacturers

A. Acceptable manufacturer: REHAU Industries LLC

1501 Edwards Ferry Road NE Leesburg, VA 20176

(703) 777-5255 | info@rehau.com | www.rehau.com/us-en

B. Substitutions: Not permitted.

C. Requests for substitutions will be considered in accordance with provisions of Section 01600.

### 2.2 RAUVISIO terra Soft, Textured HPL Surface Laminate by REHAU Industries

A. Approved product: REHAU's RAUVISIO terra Soft, Textured HPL Surface Laminate

1. RAUVISIO terra Soft, Textured HPL Surface Laminate fabricated by approved fabricator

- a. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Lakefront Elm 2633L
- b. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate East Elm 4548
- c. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Mountain Oak 2636L
- d. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Coastal Oak 4543
- e. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Mission Maple 2635L
- f. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Harvest Walnut 4604
- g. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Craft Elm 2629L  $\,$
- h. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Vineyard Oak 2640L

- i. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Northern Oak 2637L
- j. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Whiskey Oak 4511
- k. 0.9 mm RAUVISIO terra Soft, Textured HPL Surface Laminate Loft Oak 4517

# 2.3 RAUVISIO terra matching edgebanding by REHAU Industries

A. Approved product: REHAU LaserEdge™ edgebanding

- 1. RAUVISIO terra REHAU LaserEdge edgebanding, fabricated by approved manufacturer
  - a. 15/16" x 1.2 mm REHAU LaserEdge Lakefront Elm CP21076
  - b. 15/16" x 1.2 mm REHAU LaserEdge Laminate East Elm CP41161
  - c. 15/16" x 1.2 mm REHAU LaserEdge Laminate Mountain Oak CP60427
  - d. 15/16" x 1.2 mm REHAU LaserEdge Laminate Coastal Oak CP20940
  - e. 15/16" x 1.2 mm REHAU LaserEdge Laminate Mission Maple CP20949
  - f. 15/16" x 1.2 mm REHAU LaserEdge Laminate Harvest Walnut CP41369
  - g. 15/16" x 1.2 mm REHAU LaserEdge Laminate Craft Elm CP20973
  - h. 15/16" x 1.2 mm REHAU LaserEdge Laminate Vineyard Oak CP60426
  - i. 15/16" x 1.2 mm REHAU LaserEdge Laminate Northern Oak CP20976
  - j. 15/16" x 1.2 mm REHAU LaserEdge Laminate Whiskey Oak CP20941
  - k. 15/16" x 1.2 mm REHAU LaserEdge Laminate Loft Oak CP60460

# 03 Execution

### 3.1 Examination

A. Do not begin installation until all products are properly prepared and hardware installed.

### 3.2 Installation

A. Install in accordance to manufacturer's instructions found in the RAUVISIO terra technical information using screw on European concealed hinges.

## 3.3 Protection

- A. Protect installed product until completion of project.
- B. Remove peel coat after installation of product.

# 04 Links

# 4.1 RAUVISIO terra technical information

www.rehau.com/downloads/1206748/rauvisio-terra-technical-guide.pdf

# 4.2 RAUVISIO terra laminate and edgeband limited warranty

www.rehau.com/downloads/734738/standard-purchase-terms-and-conditions.pdf

### 4.3 RAUVISIO terra



# RAUVISIO terra™ Soft, Textured HPL Surface Board

Section 06400

Architectural millwork specification information

# 01 General

### 1.1 Related sections

A. Section 06410 - Custom cabinets

B. Section 12320 - Manufactured wood casework

C. Section 12350 - Specialty casework

#### 1.2 Submittals

A. Submit under provisions of Section 01300

B. Manufacturer's data sheets on product being used

1. RAUVISIO terra technical information

# 1.3 Quality assurance and testing

A. Installer qualifications: Cabinet/millwork professional

B. Testing information can be found in the RAUVISIO terra technical information

## 1.4 Storage and handling

A. Store products in manufacturer's unopened packaging until ready for installation.

- B. Store in dry, protected, well-ventilated area and protect from damage.
- C. Store away from dust and debris.

## 1.5 Safety

A. To ensure safety and proper use of the product, follow manufacturer's safety guidelines found in the RAUVISIO terra technical information.

## 1.6 Project conditions

A. Maintain environmental conditional (temperature, humidity, and ventilation) within limits recommended by manufacturer for optimal results. Do not install products under environmental conditions outside manufacturer's absolute limits.

## 1.7 Warranty

A. Provide manufacturer's limited warranty

# 02 Products

## 2.1 Manufacturers

A. Acceptable manufacturer: REHAU Industries LLC

1501 Edwards Ferry Road NE Leesburg, VA 20176

(703) 777-5255 | info@rehau.com | www.rehau.com/us-en

- B. Substitutions: Not permitted.
- C. Requests for substitutions will be considered in accordance with provisions of Section 01600.

### 2.2 RAUVISIO terra Soft, Textured HPL Surface Board by REHAU Industries

A. Approved product: REHAU's RAUVISIO terra Soft, Textured HPL Surface Board

1. RAUVISIO terra Soft, Textured HPL Surface Board fabricated by approved fabricator

- a. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Lakefront Elm 2633L
- b. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board East Elm 4548
- c. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Mountain Oak 2636L
- d. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Coastal Oak 4543
- e. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Mission Maple 2635L  $\,$
- f. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Harvest Walnut 4604
- g. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Craft Elm 2629L
- h. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Vineyard Oak 2640L

- i. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Northern Oak 2637L
- j. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Whiskey Oak 4511
- k. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Loft Oak 4517

# 2.3 RAUVISIO terra matching edgebanding by REHAU Industries

A. Approved product: REHAU LaserEdge™ edgebanding

1. RAUVISIO terra REHAU LaserEdge edgebanding, fabricated by approved manufacturer

- a. 15/16" x 1.2 mm REHAU LaserEdge Lakefront Elm CP21076
- b. 15/16" x 1.2 mm REHAU LaserEdge Laminate East Elm CP41161
- c. 15/16" x 1.2 mm REHAU LaserEdge Laminate Mountain Oak CP60427
- d. 15/16" x 1.2 mm REHAU LaserEdge Laminate Coastal Oak CP20940
- e. 15/16" x 1.2 mm REHAU LaserEdge Laminate Mission Maple CP20949
- f. 15/16" x 1.2 mm REHAU LaserEdge Laminate Harvest Walnut CP41369
- g. 15/16" x 1.2 mm REHAU LaserEdge Laminate Craft Elm CP20973
- h. 15/16" x 1.2 mm REHAU LaserEdge Laminate Vineyard Oak CP60426
- i. 15/16" x 1.2 mm REHAU LaserEdge Laminate Northern Oak CP20976
- j. 15/16" x 1.2 mm REHAU LaserEdge Laminate Whiskey Oak CP20941
- k. 15/16" x 1.2 mm REHAU LaserEdge Laminate Loft Oak CP60460

# 03 Execution

#### 3.1 Examination

A. Do not begin installation until all products are properly prepared and hardware installed.

### 3.2 Installation

A. Install in accordance to manufacturer's instructions found in the RAUVISIO terra technical information using screw on European concealed hinges.

## 3.3 Protection

- A. Protect installed product until completion of project.
- B. Remove peel coat after installation of product.

# 04 Links

# 4.1 RAUVISIO terra technical information

www.rehau.com/downloads/1206748/rauvisio-terra-technical-guide.pdf

# 4.2 RAUVISIO terra board limited warranty

www.rehau.com/downloads/1532224/rauvisio-panel-and-finished-component-limited-warranty.pdf

### 4.3 RAUVISIO terra edgeband limited warranty

www.rehau.com/downloads/734738/standard-purchase-terms-and-conditions.pdf

## 4.4 RAUVISIO terra



# RAUVISIO terra™ Soft, Textured HPL Surface Cabinet Doors

Section 06400

Architectural millwork specification information

# 01 General

### 1.1 Related sections

A. Section 06410 - Custom cabinets

B. Section 12320 - Manufactured wood casework

C. Section 12350 - Specialty casework

#### 1.2 Submittals

A. Submit under provisions of Section 01300

B. Manufacturer's data sheets on product being used

1. RAUVISIO terra technical information

# 1.3 Quality assurance and testing

A. Installer qualifications: Cabinet/millwork professional

B. Testing information can be found in the RAUVISIO terra technical information

#### 1.4 Storage and handling

A. Store products in manufacturer's unopened packaging until ready for installation.

- B. Store in dry, protected, well-ventilated area and protect from damage.
- C. Store away from dust and debris.

## 1.5 Safety

A. To ensure safety and proper use of the product, follow manufacturer's safety guidelines found in the RAUVISIO terra technical information.

#### 1.6 Project conditions

A. Maintain environmental conditional (temperature, humidity, and ventilation) within limits recommended by manufacturer for optimal results. Do not install products under environmental conditions outside manufacturer's absolute limits.

## 1.7 Warranty

A. Provide manufacturer's limited warranty

# 02 Products

## 2.1 Manufacturers

A. Acceptable manufacturer: REHAU Industries LLC

1501 Edwards Ferry Road NE Leesburg, VA 20176

(703) 777-5255 | info@rehau.com | www.rehau.com/us-en

- B. Substitutions: Not permitted.
- C. Requests for substitutions will be considered in accordance with provisions of Section 01600.

### 2.2 RAUVISIO terra Soft, Texture HPL Surface Cabinet Doors by REHAU Industries

A. Approved product: REHAU's RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors

1. RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors fabricated by approved fabricator

- a. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Lakefront Elm 2633L
- b. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors East Elm 4548
- c. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Mountain Oak 2636L
- d. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Coastal Oak 4543
- e. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Mission Maple 2635L
- f. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Harvest Walnut 4604
- g. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Craft Elm 2629L
- h. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Vineyard Oak 2640L

i. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Northern Oak 2637L

j. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Whiskey Oak 4511

k. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Loft Oak 4517

# 03 Execution

# 3.1 Examination

A. Do not begin installation until all products are properly prepared and hardware installed.

### 3.2 Installation

A. Install in accordance to manufacturer's instructions found in the RAUVISIO terra technical information using screw on European concealed hinges.

# 3.3 Protection

A. Protect installed product until completion of project.

B. Remove peel coat after installation of product.

# 04 Links

## 4.1 RAUVISIO terra technical information

www.rehau.com/downloads/1206748/rauvisio-terra-technical-guide.pdf

# 4.2 RAUVISIO terra cabinet door limited warranty

www.rehau.com/downloads/1532224/rauvisio-panel-and-finished-component-limited-warranty.pdf

## 4.3 RAUVISIO terra



# RAUVISIO terra™ Soft, Textured HPL Surface Floating Shelves

Section 06400

Architectural millwork specification information

# 01 General

### 1.1 Related sections

- A. Section 06410 Custom cabinets
- B. Section 12320 Manufactured wood casework
- C. Section 12350 Specialty casework
- D. Section 105629 Storage racks

### 1.2 Submittals

- A. Submit under provisions of Section 01300
- B. Manufacturer's data sheets on product being used
  - 1. RAUVISIO terra technical information

# 1.3 Quality assurance and testing

- A. Installer qualifications: Cabinet/millwork professional
- B. Testing information can be found in the RAUVISIO terra technical information

# 1.4 Storage and handling

- A. Store products in manufacturer's unopened packaging until ready for installation.
- B. Store in dry, protected, well-ventilated area and protect from damage.
- C. Store away from dust and debris.

# 1.5 Safety

A. To ensure safety and proper use of the product, follow manufacturer's safety guidelines found in the REHAU Floating Shelf Instruction Manual.

#### 1.6 Project conditions

A. Maintain environmental conditional (temperature, humidity, and ventilation) within limits recommended by manufacturer for optimal results. Do not install products under environmental conditions outside manufacturer's absolute limits.

# 1.7 Warranty

A. Provide manufacturer's limited warranty

# 02 Products

### 2.1 Manufacturers

A. Acceptable manufacturer: REHAU Industries LLC

1501 Edwards Ferry Road NE Leesburg, VA 20176

(703) 777-5255 | info@rehau.com | www.rehau.com/us-en

- B. Substitutions: Not permitted.
- C. Requests for substitutions will be considered in accordance with provisions of Section 01600.

### 2.2 RAUVISIO terra Soft, Texture HPL Surface Floating Shelves by REHAU Industries

A. Approved product: REHAU's RAUVISIO terra Soft, Textured HPL Surface Floating Shelves

- 1. RAUVISIO terra Soft, Textured HPL Surface Floating Shelves fabricated by approved fabricator
  - a. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Lakefront Elm 2633L
  - b. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves East Elm 4548
  - c. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Mountain Oak 2636L
  - d. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Coastal Oak 4543
  - e. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Mission Maple 2635L
  - f. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Harvest Walnut 4604  $\,$
  - q. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Craft Elm 2629L

h. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Vineyard Oak 2640L i. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Northern Oak 2637L j. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Whiskey Oak 4511 k. 60.3 mm RAUVISIO terra Soft, Textured HPL Surface Floating Shelves Loft Oak 4517

# 03 Execution

# 3.1 Examination

A. Do not begin installation until confirming all REHAU floating shelf package contents are complete and included with the shelf, per the REHAU Floating Shelf Instruction Manual.

# 3.2 Installation

A. Install in accordance to manufacturer's instructions found in the REHAU Floating Shelf Instuction Manual.

### 3.3 Protection

A. Protect installed product until completion of project.

B. Remove peel coat after installation of product.

# 04 Links

#### 4.1 RAUVISIO terra technical information

www.rehau.com/downloads/1206748/rauvisio-terra-technical-guide.pdf

### 4.2 REHAU Floating Shelf Instruction Manual

www.rehau.com/downloads/1620524/rehau-floating-shelves-installation-instructions.pdf

# 4.3 RAUVISIO terra cabinet door limited warranty

www.rehau.com/downloads/1532224/rauvisio-panel-and-finished-component-limited-warranty.pdf

## 4.4 RAUVISIO terra

