# RAUVISIO terra<sup>™</sup> Soft, Textured HPL Surface Board

Section 06400

Architectural millwork specification information

# 01 General

## 1.1 Related sections

- A. Section 06410 Custom cabinets
- B. Section 12320 Manufactured wood casework
- C. Section 12350 Specialty casework

## 1.2 Submittals

A. Submit under provisions of Section 01300

- B. Manufacturer's data sheets on product being used
  - 1. RAUVISIO terra technical information

## 1.3 Quality assurance and testing

A. Installer qualifications: Cabinet/millwork professional

B. Testing information can be found in the RAUVISIO terra technical information

## 1.4 Storage and handling

- A. Store products in manufacturer's unopened packaging until ready for installation.
- B. Store in dry, protected, well-ventilated area and protect from damage.
- C. Store away from dust and debris.

## 1.5 Safety

A. To ensure safety and proper use of the product, follow manufacturer's safety guidelines found in the RAUVISIO terra technical information.

### 1.6 Project conditions

A. Maintain environmental conditional (temperature, humidity, and ventilation) within limits recommended by manufacturer for optimal results. Do not install products under environmental conditions outside manufacturer's absolute limits.

# 1.7 Warranty

A. Provide manufacturer's limited warranty

# **02 Products**

# 2.1 Manufacturers

A. Acceptable manufacturer: REHAU Industries LLC

1501 Edwards Ferry Road NE Leesburg, VA 20176

(703) 777-5255 | info@rehau.com | www.rehau.com/us-en

- B. Substitutions: Not permitted.
- C. Requests for substitutions will be considered in accordance with provisions of Section 01600.

### 2.2 RAUVISIO terra Soft, Textured HPL Surface Board by REHAU Industries

A. Approved product: REHAU's RAUVISIO terra Soft, Textured HPL Surface Board

- 1. RAUVISIO terra Soft, Textured HPL Surface Board fabricated by approved fabricator
  - a. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Lakefront Elm 2633L
  - b. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board East Elm 4548
  - c. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Mountain Oak 2636L
  - d. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Coastal Oak 4543
  - e. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Mission Maple 2635L
  - f. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Harvest Walnut 4604
  - g. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Craft Elm 2629L
  - h. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Vineyard Oak 2640L

- i. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Northern Oak 2637L
- j. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Whiskey Oak 4511
- k. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Board Loft Oak 4517

#### 2.3 RAUVISIO terra matching edgebanding by REHAU Industries

A. Approved product: REHAU LaserEdge™ edgebanding

- 1. RAUVISIO terra REHAU LaserEdge edgebanding, fabricated by approved manufacturer
  - a. 15/16" x 1.2 mm REHAU LaserEdge Lakefront Elm CP21076
  - b. 15/16" x 1.2 mm REHAU LaserEdge Laminate East Elm CP41161
  - c. 15/16" x 1.2 mm REHAU LaserEdge Laminate Mountain Oak CP60427
  - d. 15/16" x 1.2 mm REHAU LaserEdge Laminate Coastal Oak CP20940
  - e. 15/16" x 1.2 mm REHAU LaserEdge Laminate Mission Maple CP20949
  - f. 15/16" x 1.2 mm REHAU LaserEdge Laminate Harvest Walnut CP41369
  - g. 15/16" x 1.2 mm REHAU LaserEdge Laminate Craft Elm CP20973
  - h. 15/16" x 1.2 mm REHAU LaserEdge Laminate Vineyard Oak CP60426
  - i. 15/16" x 1.2 mm REHAU LaserEdge Laminate Northern Oak CP20976
  - j. 15/16" x 1.2 mm REHAU LaserEdge Laminate Whiskey Oak CP20941
  - k. 15/16" x 1.2 mm REHAU LaserEdge Laminate Loft Oak CP60460

# 03 Execution

#### 3.1 Examination

A. Do not begin installation until all products are properly prepared and hardware installed.

### 3.2 Installation

A. Install in accordance to manufacturer's instructions found in the RAUVISIO terra technical information using screw on European concealed hinges.

### 3.3 Protection

- A. Protect installed product until completion of project.
- B. Remove peel coat after installation of product.

# 04 Links

- 4.1 RAUVISIO terra technical information www.rehau.com/downloads/1206748/rauvisio-terra-technical-guide.pdf
- 4.2 RAUVISIO terra board limited warranty www.rehau.com/downloads/1532224/rauvisio-panel-and-finished-component-limited-warranty.pdf
- 4.3 RAUVISIO terra edgeband limited warranty www.rehau.com/downloads/734738/standard-purchase-terms-and-conditions.pdf
- 4.4 RAUVISIO terra na.rehau.com/terra

