RAUVISIO terra™ Soft, Textured HPL Surface Cabinet Doors

Section 06400

Architectural millwork specification information

01 General

1.1 Related sections

A. Section 06410 - Custom cabinets

B. Section 12320 – Manufactured wood casework

C. Section 12350 - Specialty casework

1.2 Submittals

A. Submit under provisions of Section 01300

B. Manufacturer's data sheets on product being used

1. RAUVISIO terra technical information

1.3 Quality assurance and testing

A. Installer qualifications: Cabinet/millwork professional

B. Testing information can be found in the RAUVISIO terra technical information

1.4 Storage and handling

A. Store products in manufacturer's unopened packaging until ready for installation.

- B. Store in dry, protected, well-ventilated area and protect from damage.
- C. Store away from dust and debris.

1.5 Safety

A. To ensure safety and proper use of the product, follow manufacturer's safety guidelines found in the RAUVISIO terra technical information.

1.6 Project conditions

A. Maintain environmental conditional (temperature, humidity, and ventilation) within limits recommended by manufacturer for optimal results. Do not install products under environmental conditions outside manufacturer's absolute limits.

1.7 Warranty

A. Provide manufacturer's limited warranty

02 Products

2.1 Manufacturers

A. Acceptable manufacturer: REHAU Industries LLC

1501 Edwards Ferry Road NE Leesburg, VA 20176

(703) 777-5255 | info@rehau.com | www.rehau.com/us-en

- B. Substitutions: Not permitted.
- C. Requests for substitutions will be considered in accordance with provisions of Section 01600.

2.2 RAUVISIO terra Soft, Texture HPL Surface Cabinet Doors by REHAU Industries

A. Approved product: REHAU's RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors

1. RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors fabricated by approved fabricator

- a. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Lakefront Elm 2633L
- b. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors East Elm 4548
- c. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Mountain Oak 2636L
- d. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Coastal Oak 4543
- e. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Mission Maple 2635L f. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Harvest Walnut 4604
- g. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Craft Elm 2629L
- h. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Vineyard Oak 2640L

i. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Northern Oak 2637L

j. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Whiskey Oak 4511

k. 19.5 mm RAUVISIO terra Soft, Textured HPL Surface Cabinet Doors Loft Oak 4517

03 Execution

3.1 Examination

A. Do not begin installation until all products are properly prepared and hardware installed.

3.2 Installation

A. Install in accordance to manufacturer's instructions found in the RAUVISIO terra technical information using screw on European concealed hinges.

3.3 Protection

A. Protect installed product until completion of project.

B. Remove peel coat after installation of product.

04 Links

4.1 RAUVISIO terra technical information

www.rehau.com/downloads/1206748/rauvisio-terra-technical-guide.pdf

4.2 RAUVISIO terra cabinet door limited warranty

www.rehau.com/downloads/1532224/rauvisio-panel-and-finished-component-limited-warranty.pdf

4.3 RAUVISIO terra

na.rehau.com/terra

